







# S.ANSELMO

vivere la differenza

SAGOMATI VARI						
	CODICE	MISURE(mm)				
		A	B	C	D	E
	F1000	120	95	50	70	
	F1100	240	240	80	165	
	F1200	245	165	80	105	
	F1300	95	245	50	135	
	F1400	115	330	80		
	F1500	290	155	75	225	
	F1600	115	390	120	330	60
	F1800	95	250	50		
	F1900	80	275	130		
	F2000	40	250	100	190	
	F2100	155	125	60	110	

	CODICE	MISURE(mm)					
		A	B	C	D	E	F
	F2200	55	240	120	190		
	F2300	70	70	50	15		
	F2400	75	320	120	235	40	
	F2500	90	430	150	35		
	F2600	115	240	55	240	80	
	F1700	230	100	60			
	F2700	100	200	55	135		

I pezzi speciali vengono interamente realizzati a mano.  
I tempi di consegna vanno verificati con l'ufficio logistica S.Anselmo.